





## End caps



ESU

### Description

- ESU- end cap for spiral duct
- EPF- end cap for fittings



EPF

### Ordering Example

Lindab Safe (gasketed):	Type	Ød1
	ESU	aa
Lindab (nongasketed):	Type	Ød1
	ES	aa
Lindab (nongasketed):	Type	ØD <sub>1</sub>
	EPF	aa

## ESU/EPF

Ød1 (in)	ESU L (in)	EPF L (in)
3	3/8	1 <sup>5</sup> / <sub>8</sub>
4	3/8	1 <sup>5</sup> / <sub>8</sub>
5	3/8	1 <sup>5</sup> / <sub>8</sub>
6	3/8	1 <sup>5</sup> / <sub>8</sub>
7	3/8	1 <sup>5</sup> / <sub>8</sub>
8	3/8	1 <sup>5</sup> / <sub>8</sub>
9	3/8	1 <sup>5</sup> / <sub>8</sub>
10	3/8	2 <sup>3</sup> / <sub>8</sub>
12	3/8	2 <sup>3</sup> / <sub>8</sub>
14	3/8	2 <sup>3</sup> / <sub>8</sub>
16	3/8	3 <sup>1</sup> / <sub>8</sub>
18	3/8	3 <sup>1</sup> / <sub>8</sub>
20	3/8	3 <sup>1</sup> / <sub>8</sub>
22	1/2	3 <sup>1</sup> / <sub>8</sub>
24	1/2	3 <sup>1</sup> / <sub>8</sub>
26	1/2	3 <sup>1</sup> / <sub>8</sub>
28	5/8	4
30	5/8	4
32	5/8	4
34	5/8	4
36	5/8	4
38	5/8	4
40	5/8	4
42	5/8	4
44	5/8	4
46	5/8	4 <sup>3</sup> / <sub>4</sub>
48	5/8	4 <sup>3</sup> / <sub>4</sub>
50	5/8	4 <sup>3</sup> / <sub>4</sub>
52	5/8	4 <sup>3</sup> / <sub>4</sub>
54	5/8	4 <sup>3</sup> / <sub>4</sub>
56	5/8	4 <sup>3</sup> / <sub>4</sub>
58	5/8	4 <sup>3</sup> / <sub>4</sub>
60	5/8	4 <sup>3</sup> / <sub>4</sub>